



Accessories and
Spare Parts
Food Waste Disposer

in **sink**erator®

in sink erator

Brush'n'Push™

An innovative new sink tool that combines a dish brush with a pusher to help push food waste into a food waste disposer.

Strong bristles for great dish cleaning

The Brush'N'Push™ bristles are made from high quality nylon able to effectively clean dishes.

Design allows brush to stand up

At hand on your bench-top when you need it.

Thick handle for non-slip grip

The thickness of the brush allows for easy use.

Dishwasher safe

The use of high quality materials allows the Brush'N'Push™ to be cleaned in the dishwasher.

Color change indicates how far to push food waste into the disposer

The color change indicates a safe distance to push the Brush'N'Push™ into a food waste disposer.

Rubberized to grip food waste

Over-molded rubber helps grip food waste being pushed down the Food Waste Disposer.

Dimpled end to grip food waste

Dimples on the base helps grip food waste being pushed down Food Waste Disposer.



Brush'N'Push - ISE Blue
Product Code: BNPISEBlue



Brush'N'Push - Green
Product Code: BNPGreen



Brush'N'Push - Light Blue
Product Code: BNLightBlue



Brush'N'Push - Orange
Product Code: BNPOrange



Brush'N'Push - Grey
Product Code: BNPGrey

AIR SWITCH BUTTON COVERS

Customise your kitchen benchtop with an InSinkErator Air Switch Button for ease of access and a stylish finish.

For use with models 56, 66, EVO100, EVO200 or any model with an Air Switch Kit.



Chrome Finish
Product Code: IP73274K



White Finish
Product Code: IP73274J



Biscuit Finish
Product Code: IP73274B



Brushed Steel Finish
Product Code: IP73274



Mocha Bronze Finish
Product Code: IP73274D



Oil Rub Bronze Finish
Product Code: IP73274E



Glossy Black Finish
Product Code: IP73274A



Matte Black Finish
Product Code: IP73274C



French Gold Finish
Product Code: IP73274G



in sink erator[®]

SINK FLANGES AND STOPPERS

Your food waste disposer is tucked away out of sight under your sink. But, that doesn't mean that it can't make a visual statement in your kitchen. Select a custom sink flange & stopper from one of the many available finishes to give your sink a designer's touch & make a statement about your style.



Polished Stainless Finish
Product Code: Flange - IP10025P
Product Code: Stopper - IP5032A



Brushed Stainless Finish
Product Code: Flange - IP74290D
Product Code: Stopper - IP74278D



Matte Black Finish
Product Code: Flange - IP75090D
Product Code: Stopper - IP75094D



White Finish
Product Code: Flange - IP70908D
Product Code: Stopper - IP70117D



Mocha Bronze Finish
Product Code: Flange - IP75069D
Product Code: Stopper - IP75073D



French Gold Finish
Product Code: Flange - IP75083D
Product Code: Stopper - IP75087D



Square Waste Sink Adapter
Product Code: Flange - IP80000
Product Code: Evolution Strainer Plug - IP75265



Extended Stainless Sink Flange
Product Code: Flange - IP10082
Product Code: Silver Saver Stopper - IP72375D

SPARE PARTS

InSinkErator® Spare Parts use an easy to assemble, do-it-yourself style collection for your kitchen to maintain and upkeep your InSinkErator®.

Installation Kit
For models 45, 46, 55, 56, 65, 66
Product Code: IP75226B



Installation Kit
For models EVO100 & EVO200
Product Code: IP75268



Tail Pipe White
For models E20, 45, 46, 55, 56, 65, 66
Product Code: IP73238



Tail Pipe Black
For models EVO100, EVO200
Product Code: IP75436

Removable Baffle - Sound Baffle
For models 75
Product Code: IP70966



Removable Baffle - Quiet Collar Sink Baffle
For models 56, 65, 65+, 66, EVO100, EVO200
Product Code: IP77960

Polished Stainless Steel Mounting Assembly
For models 56, 66, EVO100 and EVO200
Product Code: IP3173ED



Air Switch Kit
Replacement Air Switch Single Touch button for all InSinkErator models 45, 55, LC-50.
Contains Button, Hose, Power cord & Plug, Brushed steel button also included.
Product Code: IP75369

Air Switch Button
For use with models with existing air switch button.
Product Code: IP75430B



Mounting Gasket - Standard Mounting Gasket
For models E20, 45, 45+, 46, 55, 55+, 65
Product Code: IP76894

Mounting Gasket
For models 56, 66, EVO100, EVO200
Product Code: IP74054




Stopper Gasket
Fits All Stoppers Except Evolution Strainer Plug & Plastic Stopper
Product Code: IP5029

Stopper - Plastic
Product Code: IP4310



Dishwasher Connector Connection Part
Product Code: IPMA15



Jam-Buster Wrench
Product Code: IP8305D

For service and installation, call 0800 200 510 or visit www.insinkerator.co.nz



WATER FILTERS



Don't forget to replace the filter for your InSinkErator HotTap and MultiTap.



F-701R Twin Pack Replacement Filters

- Super fine 5 micron filter for even cleaner water
- Quick-Connect Push-In Fittings guarantees a quick, easy installation
- Valve-in-Head Design automatically shuts off water flow when filter cartridge is removed, eliminating need for separate shut-off valve
- Low Pressure Drop Filter design assures consistently flawless performance
- Reduces chlorine, lead, turbidity, particulates & other unpleasant tastes and odours
- NSF Standard 42
- 6-12 month expected filter life, depending on water quality and use
- Two filter cartridges per pack

For service and installation,
call 0800 200 510 or visit
www.insinkerator.co.nz

in sink erator®