

Accessories and Spare Parts Food Waste Disposer





An innovative new sink tool that combines a dish brush with a pusher to help push food waste into a food waste disposer.

Strong bristles for great dish cleaning

The Brush'N'Push™ bristles are made from high quality nylon able to effectively clean dishes.



Design allows brush to stand up

At hand on your bench-top when you need it.

Thick handle for non-slip grip

The thickness of the brush allows for easy use.

Dishwasher safe

The use of high quality materials allows the Brush'N'Push™ to be cleaned in the dishwasher.

Color change indicates how far to push food waste into the disposer

The color change indicates a safe distance to push the Brush'N'Push $^{\sim}$ into a food waste disposer.

Rubberized to grip food waste

Over-molded rubber helps grip food waste being pushed down the Food Waste Disposer.

Dimpled end to grip food waste

Dimples on the base helps grip food waste being pushed down Food Waste Disposer.



DESIGNER AIR SWITCH BUTTONS

Customise your kitchen benchtop with an InSinkErator Air Switch Button for ease of access and a stylish finish.

For use with models 56, 66, EVO100, EVO200 or any model with an Air Switch Kit.



Vintage - Chrome Product Code: IP78666B



Vintage - Satin Nickle Product Code: IP78666



Vintage - Matte Black Product Code: IP78666A



Deco - Chrome Product Code: IP78667B



Deco - Satin Nickle Product Code: IP78667



Deco - Matte Black Product Code: IP78667A



Nautical - Chrome Product Code: IP78665B



Nautical - Satin Nickle Product Code: IP78665



Nautical - Matte Black Product Code: IP78665A



Pioneer - Satin Nickle Product Code: IP78664



Pioneer - Matte Black Product Code: IP78664A



Pioneer - Chrome

Product Code: IP78664B

Tuxedo - Chrome Product Code: IP78663B



Tuxedo - Satin Nickle Product Code: IP78663



Tuxedo - Matte Black Product Code: IP78663A

AIR SWITCH BUTTON COVERS

Customise your kitchen benchtop with an InSinkErator Air Switch Button Covers for a stylish finish on you benchtop.

For use with models 56, 66, EVO100, EVO200 or any model with an Air Switch Kit.



Chrome Finish Product Code: IP73274K



White Finish Product Code: IP73274J



Biscuit Finish Product Code: IP73274B



Brushed Steel Finish Product Code: IP73274



Mocha Bronze Finish Product Code: IP73274D



Oil Rub Bronze Finish Product Code: IP73274E



Glossy Black Finish Product Code: IP73274A



Matte Black Finish Product Code: IP73274C



French Gold Finish Product Code: IP73274G





SINK FLANGES AND STOPPERS

Your food waste disposer is tucked away out of sight under your sink. But, that doesn't mean that it can't make a visual statement in your kitchen. Select a custom sink flange & stopper from one of the many available finishes to give your sink a designer's touch & make a statement about your style.



Polished Stainless Finish Product Code: Flange - IP10025P Product Code: Stopper - IP5032A



Mocha Bronze Finish Product Code: Flange - IP75069D Product Code: Stopper - IP75073D



French Gold Finish Product Code: Flange - IP75083D Product Code: Stopper - IP75087D



Brushed Stainless Finish Product Code: Flange - IP74290D



Brushed Bronze Finish Product Code: Flange - IP77677 Product Code: Stopper -IP77681



Matte Black Finish Product Code: Flange - IP75090D Product Code: Stopper - IP75094D



Square Waste Sink Adapter Product Code: Flange - IP80000 Product Code: Evolution Strainer Plug - IP75265



White Finish Product Code: Flange - IP70908D



Extended Stainless Steel Sink Flange Product Code: Flange - IP10082 Product Code: Silver Saver Stopper - IP72375D

SPARE PARTS

InSinkErator® Spare Parts use an easy to assemble, do-it-yourself style collection for your kitchen to maintain and upkeep your InSinkErator®.



Installation Kit For models EVO100 & EVO200 Product Code: IP75268



Tail Pipe White For models E20, 45, 46, 55, 56, 65, 66 Product Code: IP73238



Tail Pipe Black For models EVO100, EVO200 Product Code: IP75436





Removable Baffle Quiet Collar Sink Baffle For models 56, 65, 65+, 66, EVO100, EVO200 Product Code: IP77960

Polished Stainless Steel Mounting Assembly For models 56, 66, EVO100 and EVO200 Product Code: IP3173ED





Air Switch Kit

In-Line Air switch, suits all InSinkErator waste disposers, installed between bench and disposer. Add-on for Model E20 and Model 46.

Product Code: IP79718





Mounting Gasket - Standard Mounting Gasket For models E20, 45, 45+, 46, 55, 55+



Product Code: IP76894







Stopper Gasket Fits All Stoppers Except Evolution Strainer Plug & Plastic Stopper Product Code: IP5029

Stopper - Plastic ProductCode: IP4310



Dishwasher Connector Connection Part Product Code: IPMA15



For service and installation, call 0800 200 510 or visit www.insinkerator.co.nz



WATER FILTERS

Don't forget to replace the filter for your InSinkErator HotTap, MultiTap & MultiTap Chilled.



F-701R Twin Pack Replacement Filters

- · Super fine 5 micron filter for even cleaner water
- Quick-Connect Push-In Fittings guarantees a quick, easy installation
- Valve-in-Head Design automatically shuts off water flow when filter cartridge is removed, eliminating need for separate shut-off valve
- Low Pressure Drop Filter design assures consistently flawless performance
- Reduces chlorine, lead, turbidity, particulates & other unpleasant tastes and odours
- · NSF Standard 42
- 6-12 month expected filter life, depending on water quality and use
- · Two filter cartridges per pack



















Accessories and Spare Parts

Food Waste Disposer

For service, advice and installation, call 0800 200 510 or visit www.insinkerator.co.nz

